




Note: When using the Aces PDM with Gen 1 systems (those with relays already wired in) you must remove the relays from the harness as the PDM is not compatible with them.

Drawing Type		
Wiring Guide PDM		
SKU	Units	Scale
AZ0040	Inch/mm	1:1.5
Rev.	Date	View
V1.0	4.2.2026	
Drawn by	Checked by	Approved by
Zik		
Aces Fuel Injection, Inc.		