




A



PINA



FUEL_PUMP A43

Main_Power+ A26

Main_Power+ A3

Main_Relay A34

Main_Relay A17

IGNSW A8

IGNSW A80

GROUND

GROUND

A1

A28

PUMP

12V Battery-

12V Battery+

Note: When using the Aces PDM with Gen 1 systems (those with relays already wired in) you must remove the relays from the harness as the PDM is not compatible with them.

Drawing Type: Wiring Guide PDM		
SKU: AZ0040	Units: Inch/mm	Scale: 1:1.5
Rev.: V1.0	Date: 5.25.2026	View
Drawn by: Zik	Checked by	Approved by

Aces Fuel Injection,Inc.